

Processing Crystal Melt & Pour Bases

1



Open & Cut

Simply open the packaging and remove the base. Safely cut the Crystal soap base into smaller cubes, doing this will make the soap easier to handle and melt.

2



Melt & Mix

Gradually heat the soap base to around 75°C/149°F. Mix gently ensuring that any fragrance or additives* you have added are evenly distributed.

**Use up to 3% additives, including a maximum of 1% fragrance*

3



Pour & Set

Working quickly, simply pour your soap base into your soap mould. Spray with rubbing alcohol to prevent bubbles forming on the surface. Allow your base to cool & set completely before unmoulding.

4



Remove

Once set, remove from the mould. The bars will release more easily if it has been left for 24 hours in a cool place. Once hard, package as required. If the finished product is to be sliced, we recommend using a soap wire cutter.

