

Easy Lotion
Processing Instructions

CONVERTING EASY LOTION INTO A FINISHED PRODUCT

1. Add required amount of Easy lotion to a beaker.
2. Using a suitable stirring utensil add colour, fragrance and or oils as required (up to 3% extra oil can be added, recommended fragrance level up to 1% fragrance dependant). Stir for 5 - 10 minutes or until all the added ingredients have fully dispersed (Do not stick blend or high shear oils into product).

N/B – For larger production batches, processing should be scaled up appropriately. Consideration will need to be given to stirring equipment and appropriate filling equipment.

3. Fill into the required containers.
4. Take sample for microbiological testing both before and after filling

Please note:

1. ***Like all water based personal care products, Lotion Base is susceptible to microbial contamination, even though it has passed microbial preservative challenge testing. Good hygiene and good manufacturing practices must be carried out when using this product at all times.***
2. ***Like all lotions your formulations should first pass stability testing and microbial preservative challenge testing before you manufacture them.***

Revision Number 03

T +44 (0) 113 205 0900

Registered in England No. 68499 Registered Office:

Brookfoot House, Low Lane, Horsforth, Leeds, LS18 5PU, UK

www.stephensonpersonalcare.com

hello@stephensongroup.co.uk

