

**Lotion Base
Processing Conditions
89% Organic Ingredients**

Converting Lotion Base Into A Finished Product

1. To a sterilised vessel with a suitable stirrer (preferably with variable speed), lid and preferably with a heater, add the Lotion Base.

Please note:

The best type of agitation is likely to have large blades that go close to the edge of the sides of the vessel. Just a small propeller stirrer in the middle of the vessel may not be sufficient.

2. With the stirrer on slow heat the lotion base to 38 – 40°C. Add organic essential oils as required (typically add 0.2 – 0.5%). Stir for 15 – 30 minutes or until all the oil has fully dispersed.
3. Fill into the required containers.
4. Take sample for microbiological testing both before and after filling

Please note:

1. *Like all water based personal care products, Lotion Base is susceptible to microbial contamination, even though it has passed microbial preservative challenge testing. Good hygiene and good manufacturing practices must be carried out when using this product at all times.*
2. *Like all lotions your formulations should first pass stability testing and microbial preservative challenge testing before you manufacture them.*

T +44 (0) 113 205 0900

Registered in England No. 68499 Registered Office:

Brookfoot House, Low Lane, Horsforth, Leeds, LS18 5PU, UK

www.stephensonpersonalcare.com

hello@stephensongroup.co.uk





Revision Number 01

T +44 (0) 113 205 0900

Registered in England No. 68499 Registered Office:

Brookfoot House, Low Lane, Horsforth, Leeds, LS18 5PU, UK

www.stephensonpersonalcare.com

hello@stephensongroup.co.uk

