

Premium Conditioner Processing Instructions

1. Add required amount of Premium Conditioner to a beaker.
2. Using a suitable stirring utensil add colour and or desired fragrance/extract to product. It is recommended that no more than 2% fragrance/extract is added to the product.

N/B – For larger production batches, processing should be scaled up appropriately. Consideration will need to be given to stirring equipment and appropriate filling equipment.

3. Fill into the required containers.
4. Take sample for microbiological testing both before and after filling

Please note:

1. ***Like all water based personal care products, Premium Conditioner is susceptible to microbial contamination, even though it has passed microbial preservative challenge testing. Good hygiene and good manufacturing practices must be carried out when using this product at all times.***
2. ***Like all your products, formulations should first pass stability testing and microbial preservative challenge testing before you manufacture them***
3. ***The Premium Conditioner base is pre thickened, and shouldn't lose viscosity when fragrance is added. Should you wish to increase the viscosity, high sheer can be used to build to desired specification. If the base is thickened beyond desired viscosity, water can be used to thin the base. If any additional water is added to the base it will need to be submitted for challenge testing to ensure the preservative system is still effective.***

Revision Number 01

T +44 (0) 113 205 0900

Registered in England No. 68499 Registered Office:

Brookfoot House, Low Lane, Horsforth, Leeds, LS18 5PU, UK

www.stephensonpersonalcare.com

hello@stephensongroup.co.uk

